

# Protect your investment.

How to care for your fabric.

Fabric: Durango  
Type: Vinyl



To ensure that your fabric lasts, it is important to treat it correctly. Follow the vendor cleaning instructions below for the best result.

## CLEANING CODES

**WS: Water/Solvent Cleaner** - Spot clean with a mild solvent, an upholstery shampoo, or the foam from a mild detergent. When using a solvent or dry cleaning product, follow instructions carefully and clean only in a well-ventilated room. Avoid any product that contains carbon tetrachloride or other toxic materials. With either method, pretest a small area before proceeding. Always rinse promptly with clean water.

**CFC: Coated Fabrics Cleaning** - When a spill/stain occurs wipe immediately with a clean dry cloth. Carefully remove the majority of the stain then follow the steps below.

**Soap & Water** - Remove ordinary dirt and smudges with a mild soap and water solution using a soft cloth or towel. Rinse with fresh water and wipe dry.

**Non-abrasive Cleaners** - If residue remains, use a straight application of the following cleaners: Fantastik or 409 and gently clean with a soft cloth. Rinse with fresh water and wipe dry.

**Isopropyl Alcohol** - More stubborn stains may be eliminated using a cotton cloth soaked in 70-91% isopropyl (rubbing) alcohol. Wipe without spreading stain to surrounding area. A second application should be applied with vigorous rubbing in a circular motion. For highly textured material, a soft brush is recommended to clean valleys and crevices. Rinse with fresh water and wipe dry.

**BC: Bleach Cleanable** - 1 parts bleach, 9 parts water = 10% bleach, 90% water solution. Do not clean / disinfect fabric for longer than 10 minutes using the 10% bleach solution. Always rinse promptly with clean water after applying the bleach solution. Failure to do so will void any and all warranties.

*Please note: If specific cleaners are not listed, then the pattern has not been tested for cleaning solution compatibility.*

## APPROVED DISINFECTANTS AND CLEANERS

- 3m Disinfectant Cleaner RCT Concentrate
- 3m HB Quat Disinfectant Cleaner Concentrate 25I
- 3m HB Quat Disinfectant Concentrate
- Asepticare
- Asepticare TB-II
- Avert Spracidal Disinfectant Cleaner
- Avistat-D RTU Spray Disinfectant Cleaner
- Birex SE Disinfectant
- Bleach (Ratio of Water to Bleach 9:1)
- Bleach-Rite Disinfecting Spray
- Cavicide
- Cavicide 1
- Caviwipes XI
- Citrace Germicide
- Clean On The Go HDQ C2 Neutral Disinfectant
- Clorox Broad Spectrum Quaternary Disinfectant Cleaner
- Clorox Healthcare Bleach Germicidal Cleaner
- Clorox Healthcare Bleach Germicidal Wipe
- Clorox Healthcare EZ-Kill Quat Alcohol Cleaner
- Clorox Healthcare Fuzion Cleaner Disinfectant
- Clorox Healthcare Hydrogen Peroxide Cleaner Disinfectant
- Clorox Healthcare Versasure Cleaner Disinfectant
- Clorox Hydrogen Peroxide Cleaner Disinfectant Spray
- Concept 256N
- Dispatch Hospital Cleaner Disinfectant With Bleach
- ERC Performance Wipes
- Evaclean Purtabs
- Fade-A-Dyne II
- Fantastik All Purpose Cleaner
- Formula 409 All Purpose Cleaner
- Fresh Breeze TB Detergents
- Halomist
- Hepastat 256
- Isopropyl Alcohol
- J-512 Sanitizer
- Kennelsol
- Lysol Spray Disinfectant
- NLV-2 Disinfectant Cleaner & Virucide
- Optim 33 TB Disinfectant (Alternate for Accel TB)
- Oxivir 1 RTU
- Oxivir TB
- Oxivir TB Wipes
- Oxycide Daily Disinfectant Cleaner
- Peroxide Multi Surface Cleaner And Disinfectant
- Power Quat
- Purell Healthcare Surface Disinfectant
- Purell Multi Surface Disinfectant
- Rejuvenate RTU Wipes One Step
- Re-Juv-Nal
- Sani Cloth Af3 Germicidal Wipes (Grey Lid)
- Sani Cloth Bleach Germicidal Wipes (Orange Lid)
- Sani Cloth Hb Germicidal Wipes (Green Lid)
- Sani Cloth Plus Germicidal Wipes (Red Lid)
- Sani-24 Germicidal Spray
- Sani-Hypercide Germicidal Spray
- Sani-Prime Germicidal Spray
- Sani-Professional Multi Surface Wipes
- Sanizide Plus Surface Disinfectant Spray
- Steri-7 Xtra Concentrate
- Steri-7 Xtra Wipes
- Super HDQ L 10
- Super Sani Cloth Germicidal Wipes (Purple Lid)
- TB-Cide Quat
- Vert-2 Go Ed
- Virex II 256- Concentrate
- Virex Plus One-Step Disinfectant Cleaner & Deodorizer
- Virox 5 Concentrate (1:256 Dilution; CN Product)
- Virox 5 RTU (CN Product)
- Virox AHP 5 Disinfectant Cleaner Surface Wipes
- Vital Oxide
- Wex-Cide 128 Cleaner

## NON-APPROVED DISINFECTANTS AND CLEANERS

- Perisept 62 Sporicidal Disinfectant
- Hydrolyt

The results for the cleaners/disinfectants listed does not imply "approved" or that the results are guaranteed. These evaluations are indicators after laboratory testing and may not be indicative of field performance. Customers should first determine if products are appropriate for use on their surfaces.

The majority of today's disinfectant chemistries are mainly designed for use on hard environmental surfaces such as ceramic, porcelain, laminate, steel etc. After each application these types of disinfectants on seating surfaces the surface must be wiped with clean water and dried with a clean towel to remove any chemical residue that could eventually discolor or degrade the material surface. Failure to follow the above dilution recommendations, directions when using these types of cleaners/disinfectants or the application of a clean water rinse after each application can expedite a product failure and will void any warranty claim.



Scan to view complete fabric specification information from the vendor.

For additional questions or assistance, contact your Regional Sales Rep or Butler Customer Support.



413-A Branchway Road  
North Chesterfield, Virginia 23236  
877.852.0784 | 804.897.0053 f  
sales@butlerhumanservices.com  
[butlerhumanservices.com](http://butlerhumanservices.com)